

NOTES FOR USE AND CARE OF DIGITAL MEASURING EQUIPMENT

1- Avoid contact with coolant/liquid or swarf . This will damage the circuit and display. Keep the unit clean at all times

2-Avoid contact with magnets . This will damage the display

3- Avoid working with the unit in cold temperatures or extremes of temperatures . It is advisable to work with the unit in a warm workshop as cold environments will drain the batteries very quickly.

4- If the unit comes on by itself when not in use this may indicate that the battery needs replacing and / or you are working in a cold environment.

5 - If the numbers in the display keep flashing this may indicate that the battery needs replacing

6- When replacing the battery , keep the battery compartment empty for at least a minute before putting the new battery in.

7 - Batteries can become weak - even when not installed in a unit- it may be advisable to check the strength of a replacement battery before using as they do have a shelf life