


## Step 1:Zero

Instructions:

1. Flip over the device, make the top surface of the device touch with the surface of worktable or workpiece.
2. Long press zero button to reset the position to 0.



## Step 2:Operation

